



INDICATOR LIGHT

1. When using

Flash twice then glow once=Power on Glow once then flash twice=Power off White=In use

Red=Power less than 30% Both Red and White light flash 10 times in sucession = Out of battery

2. When charging Red=Charging White=Fully charged

TWO SPECIAL CIRCUMSTANCES **USERS SHOULD KNOW**

- 1. For longer duration of use, the device provides two use modes: normal mode and power saving mode, which will be activated when the battery capacity gets down to 30%.
- 2. The output will shut off automatically when vaping time exceeds 10 seconds in case of overheating.

DOs

Only use prime pods with the prime pod battery, powered by iKrusher's VFIRE technology.

Always prime new cartridge before vaping. Keep this device in a cool, dry place when you're not using it.

Keep this device away from children and pets.

DON'Ts

Don't dry burn. Don't use during charging.

Don't refill the cartridge.

Don't use if there is insufficient e-liquid inside. Don't use the adapters which are damaged, or without being CE/UL/FLL certified.

THIS PRODUCT IS NOT SUITABLE FOR USE BY:

- Persons who are not certified patients in the Commonwealth medical marijuana program.
- -Pregnant or breast-feeding persons
- -Persons with unstable heart condition, severe hypertension or diabetes









For more product details, please visit www.primewellnesspa.com



O @prime.wellness